



## SIGNAL TRANSDUCERS

Transducer  
UBS-4TR/CV/S



Resistance thermometer input

Transducer  
UBSZ-8TL/CV/S



Thermocouple input

Transducer  
UBSZ-4TR/8TL/C



Resistance thermometer/  
thermocouple input

Transducer  
UBSZ-8TL/C



Thermocouple input

Transducer  
UBS-D/CV/S



Potentiometer input

Transducer  
UBSZ-8TL/CVR/S



Thermocouple input,  
alarm setting

Transducer  
UBS-4TR/CVR/S



Thermocouple input,  
alarm setting

ACV transducer  
UBS-VAC/CV/S



Voltage signal

ACA transducer  
UBS-IAC/CV/S



Current signal

ACA transducer  
UBS-IAC/CV/SP



Current signal